

On a recent morning, a crew attempting to install a chemical blind was splashed with gasoline and light ends materials. Some of the gasoline penetrated through the front zipper of the chemical suit coming in contact with the abdomen area of a contract employee, to prevent this from happening again we need to start putting chemical tape over the front zipper. The picture below illustrates how the chemical tape should be applied.

